



(i): Always install Sopradrain filter fabric towards soil retention system. Primer is recommended over drainage board for application below 10°C.