



COPYRIGHT 2018 SOPREMA



1688, J-B Michaud
Drummondville, QC J2C 8E9
WWW.SOPREMA.CA

NOTES:

(i): Use SOPRASEAL STICK PRIMER, ELASTOCOL STICK H₂O or ELASTOCOL STICK ZERO with self-adhesive membranes and ELASTOCOL 500 with heat-welded membranes.

(ii): Use SOPRASEAL SEALANT with self-adhesive or liquid membranes and SOPRAMASTIC with heat-welded membranes.

TITLE:		MASONRY WALL FOUNDATION JUNCTION	
PROJECT:		DRAWING NUMBER:	
SCALE:	N.T.S.	DATE:	APRIL 2018
			PAR04