



COPYRIGHT 2018 SOPREMA



1688, J-B Michaud  
 Drummondville, QC J2C 8E9  
 WWW.SOPREMA.CA

TITLE: COLPHENE LM BARR CURB AND PARAPET

PROJECT:	DRAWING NUMBER:
SCALE: N.T.S.	BARR01
DATE: AUGUST 2018	

(i): Always install SOPRADRAIN filter fabric towards backfill and on to footing.