



(i): Always install SOPRADRAIN filter fabric towards backfill and on to footing.

COPYRIGHT 2018 SOPREMA



1688, J-B Michaud
Drummondville, QC J2C 8E9
WWW.SOPREMA.CA

TITLE:			COLPHENE LM BARR STATIC JOINT LESS THAN 1/2"
PROJECT:		DRAWING NUMBER:	
SCALE:	N.T.S.	DATE:	AUGUST 2018
			BARR02