


COPYRIGHT 2018 SOPREMA

		1688, J-B Michaud Drummondville, QC J2C 8E9 WWW.SOPREMA.CA	
		TITLE: COLPHENE LM BARR EXPANSION JOINT LESS THAN 1/2"	
PROJECT:		DRAWING NUMBER:	
SCALE:	N.T.S.	DATE:	AUGUST 2018
			BARR03

(i): Always install SOPRADRAIN filter fabric towards backfill and on to footing.