

Note 1: Provide vegetation-free zone at the base of upstands, around drains and roof projections as per applicable standards. Note 2 : The side boards must be removed once the TOUNDRA BOX are installed

COPYRIGHT 2020 SOPREMA

Title: SOPRANATURE - TOUNDRA BOX ON CONVENTIONNAL ROOF

Drawing number: Date: Scale: N.T.S. SEPT. 2020 SNAT11