

TECHNICAL BULLETIN

TECHNICAL BULLETIN
1014CE
(supersedes -)

OBJECT: CABOT GYPSUM BOARDS

SELF-ADHESIVE MEMBRANES

Sheating treated core and BlueGlass sheating gypsum boards from Cabot are accepted as suport for the installation of **SOPRASEAL STICK 1100T** and **LASTOBOND SHIELD** self-adhesive membranes.

The use of **ELASTOCOL STICK** primer is required before the installation of the self-adhesive membranes.

SOPREMA general recommendations regarding surface preparation and membrane installation (including temperature limitations) apply to these boards and remain unchanged.

- END OF TECHNICAL BULLETIN -