



Note 1 : Fastening bars are recommended when base sheet membranes of the field surface are adhered with hot bitumen.

Note 2 : Use self-adhesive membrane if combustible materials are use in the system (ex.: wood fibre, polystyrene, etc.).

COPYRIGHT 2020 SOPREMA

Title : SAFETY UPSTAND WITH BATTEN BAR
FOR TRANSVERSAL MEMBRANES (XMD)

Scale:
N.T.S.

Date:
AUGUST 2020

Drawing number:
SOP106-03