



NOTE:
 (i) SOPRA-ISO V PLUS: For tape at joints and fasteners, use SOPRASEAL STICK 600 TC with SOPRASEAL STICK PRIMER.

COPYRIGHT 2018 SOPREMA

Title: WALL-FOUNDATION JUNCTION - SOPRA-ISO V PLUS - SOPRA-SPF - STEEL STUD		
Scale: N.T.S.	Date: January 2018	Drawing number: SOP310-03