



Note: Depending on the type of membrane, install insulation board with adhesive or fasteners without perforate the membrane.

(i): Always install SOPRADRAIN filter fabric towards backfill and on to footing.

(ii): Use SOPRASEAL STICK PRIMER with self-adhesive membrane and ELASTOCOL 500 primer with thermofusible membranes.

(iii): Use the membrane installed on the foundation wall for the reinforcement membrane.

COPYRIGHT 2019 SOPREMA

Title:
FOUNDATION

Scale:
N.T.S.

Date:
January 2019

Drawing number:
SOP402-01