



PLAN VIEW

(i): Always install SOPRADRAIN filter fabric towards backfill and on to footing.

COPYRIGHT 2018 SOPREMA

Title:  
EXPANSION JOINT - COLPHENE LM BARR

Scale:  
N.T.S.

Date:  
January 2018

Drawing number:  
SOP406-01