



**NOTE 1: COLPHENE H SYSTEM**

Apply the base coat of COLPHENE H at a minimum thickness of 2.3 mm (90 mils) to the substrate. Immediately unroll the reinforcing fabric (SOPRAFLASH R) with a 75 mm (3 in) overlap of adjacent sheets into the base coat of COLPHENE H while in hot liquid state. Apply the top coat of COLPHENE H at a minimum rate of 3.2 mm (125 mils) over the reinforcing fabric.

COPYRIGHT 2018 SOPREMA

Title:  
PLAZA DECK WITH BACKFILL - INSULATED - COLPHENE H

Scale:  
N.T.S.

Date:  
May 2018

Drawing number:  
SOP500-02

