



NOTES:

- (i): Always install sopradrain filter fabric towards backfill.
- (ii): Seal all terminations (horizontal and vertical) with trowel with a round end.

COPYRIGHT 2018 SOPREMA

Title:
PLAZA DECK - DRAIN

Scale:
N.T.S.

Date:
May 2018

Drawing number:
SOP514-01