



(i): Always install SOPRADRAIN filter fabric towards backfill and on to footing.

COPYRIGHT 2018 SOPREMA

Title:
PLAZA DECK - COLPHENE LM BARR - PARAPET

Scale:
N.T.S.

Date:
October 2018

Drawing number:
SOP515-01

