



**NOTES:**

(1) : Use SENTINEL S BONDING ADHESIVE with bare-back membranes and DUOTACK SPF with fleece-back membranes. See detail 143-01 for an alternative perimeter fastening solution.

COPYRIGHT 2021 SOPREMA

**Title:**  
PVC PARAPET - METAL CAPPING

**Scale:**  
(N.T.S.)

**Date:**  
MARCH 2021

**Drawing number:**  
SOP140-01