



Notes:  
 (1) This distance is to accommodate a minimum 38 mm (1.5 in) heat welded seam to field membrane.  
 (2) Use SENTINEL S BONDING ADHESIVE with bare-back membranes and DUOTACK SPF with fleece-back membranes.  
 COPYRIGHT 2021 SOPREMA

Title:  
 PVC UPSTAND - HORIZONTAL PERIMETRIC FASTENERS

Scale: N.T.S.	Date: MARCH 2021	Drawing number: SOP143-01
------------------	---------------------	------------------------------