



WATERPROOFING

SOPRASEAL[®] STICK 1100 T WALLS



SELF-ADHESIVE AIR/VAPOUR BARRIER MEMBRANE



SOPRASEAL STICK 1100 T is a self-adhesive air/vapour barrier membrane for walls composed of SBS modified bitumen and a tri-laminate woven polyethylene facer. It is also used as masonry and through-wall flashing membrane as well as waterproofing membrane at openings and transitions.

- Excellent adhesion to various substrates
- Ideal for sprayed polyurethane foam insulation
- Easy, fast and economical to install
- Self-sealing membrane ensuring continuous waterproofing

SURFACE PREPARATION

Substrates must be clean and dry, primed with SOPRASEAL STICK PRIMER, ELASTOCOL STICK ZERO or ELASTOCOL STICK H₂O to ensure better adhesion.

COMPLEMENTARY PRODUCTS

SOPRASEAL STICK PRIMER, ELASTOCOL STICK ZERO & ELASTOCOL STICK H₂O

Used to prepare surfaces before the installation of self-adhesive membranes.

SOPRASEAL STICK 1100T in cut rolls

Ensure sealing of various openings.

SOPRAMASTIC

Ideal complement to bituminous waterproofing membranes as joint filler and caulking material.

SOPRASEAL STICK 1100 T

THICKNESS	1.0 mm (40 mil)
DIMENSIONS	0.91 x 22.9 m (3 x 75 ft)
SURFACE	Tri-laminate woven polyethylene
UNDERFACE	Silicone release paper



SOPREMA.US • 1.800.356.3521

SOPREMA.CA • 1.877.MAMMOUTH

INSTALLATION INSTRUCTIONS

1



Prime the substrate with SOPRASEAL STICK PRIMER, ELASTOCOL STICK ZERO or ELASTOCOL STICK H₂O.

2



Peel off the top portion of the silicone release paper and adhere the membrane to the substrate, making sure the membrane is well aligned.

3



Gradually peel off the remaining silicone release paper, making sure the membrane adheres completely to avoid air pockets and wrinkles.

4



Use a roller to apply pressure over the entire surface of the membrane to ensure uniform adhesion to substrate.

5



Use SOPRAMASTIC to seal around details, reverse laps and critical areas. For window openings, use a compatible sealant.

If you have any questions about this product or its installation, please contact your SOPREMA representative.



SOPREMA.US • 1.800.356.3521

SOPREMA.CA • 1.877.MAMMOUTH