

# RESISTO®

## ALL-WEATHER BUTYL FLASHING TAPE INSTALLATION GUIDE

INSTALLATION RECOMMENDED BY RESISTO

1



Insert the ALL-WEATHER BUTYL FLASHING TAPE corner guards on the weather barrier to prevent infiltration.

Mechanically secure the ALL-WEATHER BUTYL FLASHING TAPE corner guards.

2



Apply an ALL-WEATHER BUTYL FLASHING TAPE strip on the lower part of the window and cover 2 to 3 in (5 to 7.5 cm) of the weather barrier.

Cut the membrane on each side of the opening and adhere it with a membrane roller.

3



Install a membrane strip from 2 to 3 in (5 to 7.5 in) on the weather barrier.

4



Lift the upper weather barrier.

Adhere an ALL-WEATHER BUTYL FLASHING TAPE strip to cover the top of the window.

5



Install the metal flashing according to the building code.

6



Fold the weather barrier membrane in place.

Cut 1 in (2.5 cm) of the weather barrier to clear the metal flashing.

7



Seal the metal flashing corners by installing an ALL-WEATHER BUTYL FLASHING TAPE membrane strip obliquely on each end.

# RESISTO®

Please contact your dealer directly or go to [www.resisto.ca](http://www.resisto.ca) for more information about this product.