

RESISTO®

ALL-WEATHER BUTYL FLASHING TAPE

RESISTO ALL-WEATHER FLASHING TAPE IS A SELF-ADHESIVE RUBBERIZED BUTYL MEMBRANE THAT PREVENTS AIR AND WATER INFILTRATION. IT IS EASY TO APPLY ON WOOD, ALUMINUM, POLYETHYLENE, PVC, AIR-BARRIER MEMBRANES, AND FIBREGLASS GYPSUM SHEATHING.

SIZES AVAILABLE

No. 22767	4 in (10 cm) × 75 ft (22.9 m)
No. 22858	6 in (15 cm) × 75 ft (22.9 m)
No. 22860	9 in (23 cm) × 75 ft (22.9 m)
No. 22859	12 in (30 cm) × 75 ft (22.9 m)



Superior adhesion in a **wide range of temperatures** from **5 °F to 149 °F (-15 °C to 65 °C)**



No primer needed, allowing for quick installation



The maximum adhesive strength is reached within 12 to 24 hours

During the installation process, the membrane is easy to handle thanks to its initial adhesive properties



Compliance with the rigorous requirements of **AAMA 711**, which is recognized by most regulatory authorities



Thin tape which **eliminates excess thickness** and keeps the opening of the frame clear to facilitate the insertion of a window or door



Easy installation thanks to the split-back release silicone film



Self-sealing properties around nails, screws and fasteners



UV resistant for **180 days**



RESISTO[®]

ALL-WEATHER BUTYL FLASHING TAPE INSTALLATION GUIDE

INSTALLATION RECOMMENDED BY RESISTO

1



Insert the ALL-WEATHER BUTYL FLASHING TAPE corner guards on the weather barrier to prevent infiltration.

Mechanically secure the ALL-WEATHER BUTYL FLASHING TAPE corner guards.

2



Apply an ALL-WEATHER BUTYL FLASHING TAPE strip on the lower part of the window and cover 2 to 3 in (5 to 7.5 cm) of the weather barrier.

Cut the membrane on each side of the opening and adhere it with a membrane roller.

3



Install a membrane strip from 2 to 3 in (5 to 7.5 in) on the weather barrier of the joist.

4



Lift the upper weather barrier.

Adhere an ALL-WEATHER BUTYL FLASHING TAPE strip to cover the top of the window.

5



Install the metal flashing according to the building code.

6



Fold the weather barrier membrane in place.

Cut 1 in (2.5 cm) of the weather barrier to clear the metal flashing.

7



Seal the metal flashing corners by installing an ALL-WEATHER BUTYL FLASHING TAPE membrane strip obliquely on each end.

RESISTO[®]

Please contact your dealer directly or go to www.resisto.ca for more information about this product.