



SOPREMA

EN

IFLEX

INSTALLATION

1. Staple I-Flex to the studs, reflective surface facing in toward the room;
2. Seal the joints with ALUMINUM FOIL TAPE;
3. Install 1 x 3 inch wooden slats perpendicular to the studs every 400 mm (16 inches).
They will create an air space between the drywall and the I-Flex, optimizing the R-value.
4. Install the drywall panels onto the wooden slats.

FR

IFLEX

INSTALLATION

1. Agrapper I-Flex sur les montants de bois de la structure, côté réfléchissant vers l'intérieur de la pièce;
2. Sceller les joints avec le RUBAN MÉTALLISÉ ALUMINIUM;
3. Installer des lattes de bois de 1 pouce x 3 pouces perpendiculairement aux montants de bois à tous les 400 mm (16 pouces). Ces dernières serviront à créer l'espace d'air entre le gypse et l'I-Flex pour optimiser la valeur isolante.
4. Installer les panneaux de gypses sur les lattes de bois.

ES

IFLEX

INSTALACIÓN

1. Engrape I-Flex a los montantes, con la superficie reflectante hacia la habitación;
2. Selle las juntas con CINTA DE ALUMINIO;
3. Instale listones de madera de 1 x 3 pulgadas perpendiculares a los montantes cada 400 mm (16 pulgadas). Crearán un espacio de aire entre el panel de yeso y el I-Flex, optimizando el valor R.
4. Instale los paneles de yeso sobre los listones de madera.