

# SOPRA TPE PIPE COLLAR

TECHNICAL DATA SHEET

N7-TDS-126-SOPRA TPF PIPF COLLAR

ROOFS FOUNDATIONS CIVIL WORKS

**APPLICATIONS** 

#### DESCRIPTION

SOPRA TPE PIPE COLLAR is used on roofing or underground waterproofing system assembled with SOPREMA bituminous membranes to give continuity to the waterproofing around elements that come out from the roof or foundations.

SOPRA TPE PIPE COLLAR have slightly conical shape of the shank makes it easier to install through tubes and the perforated flange favours adhesion with bituminous sheaths.

Easy and quick to install

Rot-proof

High puncturing resistance

**Excellent** weldability

#### **APPLICATION**

- SOPRA TPE PIPE COLLAR are adhered onto a melted bitumen with torch or hot air all along the flange perimeter on the bitumem membranes.
- Installe a 400mm by 400mm patch of bitumen membrane or the capsheet fully torch over the flange with an opening for the pipe.
- Tighten the upper end of SOPRA TPE PIPE COLLAR with a stainless steel clamp.
- · SOPRA TPE PIPE COLLAR is compatible with all the accessories and membrane in the SOPREMA bitumen range.

FOR COMPLETE INFORMATION ON PRODUCT INSTALLATION, PLEASE CONSULT YOUR SOPREMA REPRESENTATIVE.

## **PACKAGING**

SPECIFICATIONS	SOPRA TPE PIPE COLLAR					
Appearance	Black					
Packaging	25 units per box					



# **PROPERTIES**

PROPERTIES		SOPRA TPE PIPE COLLAR									
		C10	C12	C30	C40	C60	C80	C100	C120	C140	C160
Width at flange	Α	154 mm	154 mm	154 mm	154 mm	194 mm	194 mm	234 mm	234 mm	274 mm	274 mm
Internal diameter at bottom	В	11 mm	14 mm	32 mm	42 mm	62 mm	82 mm	102 mm	122 mm	142 mm	162 mm
Internal diameter at top	C	10 mm	12 mm	30 mm	40 mm	60 mm	80 mm	100 mm	120 mm	140 mm	160 mm
Height	h	60 mm	60 mm	60 mm	60 mm	60 mm	60 mm	90 mm	90 mm	90 mm	90 mm

## STATEMENT OF RESPONSIBILITY

The technical information and application advice given in this publication is based on the present state of our best knowledge. As the information herein is of a general nature, no assumption can be made as to a product's suitability for a particular use or application and no warranty as to its accuracy, reliability or completeness either expressed or implied is given other than those required by Commonwealth or State Legislation. The owner, their representative and/or the contractor are responsible for checking the suitability of products for their intended use.





