RESISTO

LASTOBOND PRO HT-N

EAVE PROTECTOR | UNDERLAYMENT



High performance self-adhesive underlayment for metal roofs, or as a perimeter membrane under one-ply roofing system and asphalt shingles. It is designed to withstand temperature variations from -45 $^{\circ}$ C to 90 $^{\circ}$ C (-49 $^{\circ}$ F to 194 $^{\circ}$ F).

- Excellent resistance to temperature variations
- Easy Installation
- UV resistant; 90-day exposure

PRODUCT PURPOSE

Application	Wateproofing		
Building Part	Roofing		
Types of slope	Outside steep slope	Outside low slope	
Type of covering	Sheet metal	Asphalt shingles	
	Bitumen membrane		
Substrates	Plywood	Asphaltic panel	
	OSB		

PRODUCT CHARACTERISTICS

Technology	SBS modified bitumen
Surface	Trilaminate woven polyethylene
Underface	Two parts silicone release film (split-back)
Installation Method	Self-adhesive
Operating temperature	-45 °C to 90 °C (-49 ° F to 194 °F)
Maximum exposure	90 days

PACKAGING

Code	Width		Length		I I nirkness		Selvedge Width		Net Area				Quantity
	m	in	m	ft	mm	mil	mm	in	m²	ft ²	m²	ft ²	(per pallet)
10107	0.91	36	20	65	1	40	75	3	16.7	179	18.2	195	25

PROPERTIES

Properties	STANDARDS	LASTOBOND PRO HT-N
Roll Weight	-	20 kg (44 lbs)
Breaking Strength, MD / XD	ASTM D1970	11 / 12 kN/m (63 / 68 lbf/in)
Elongation at break, MD / XD	ASTM D1970	30 / 20%
Tear Resistance, MD / XD	ASTM D1970	375 / 400 N (84 / 90 lbf)
Static Puncture	ASTM D5602	400 N (90 lbf)
Adhesion to plywood, 4,5 $^{\circ}$ C (40 $^{\circ}$ F)	ASTM D1970	12 kgf/30.5 cm (26 lbf/ft)
Adhesion to plywood, 24 °C (75 °F)	ASTM D1970	31 kgf/30.5 cm (68 lbf/ft)
Low Temperature Flexibility	ASTM D1970	Pass at -30 °C (-22 °F)
Water vapour permeance	ASTM E96 (Procedure B)	< 2.1 ng/Pa.s.m ² (< 0.037 perm)
Nail Sealability	ASTM D1970	Pass

RESISTO

LASTOBOND PRO HT-N

INSTALLATION

Storage	protective cover after removing the deliv	up. If the products are stored outdoors, cover them with an opaque very packaging. Stivated to at least 5 ° C (41 ° F) before installation.
Minimum Application Temperature	5 °C (41 °F)	
Complementary Products	EXTERIOR PRIMER	OR H ₂ O PRIMER
Tools Required	Knife	Smoothing roller
	Tape measure	

	The use of EXTERIOR PRIMER or H ₂ O PRIMER is not required on most surfaces when the membrane is covered within 24 hours of installation. However, primer is mandatory when membrane is used as underlayment in a RESISTO single-ply roofing system. 1. If conditions require, prepare the substrate with EXTERIOR PRIMER or H ₂ O PRIMER. 2. Position the mambrane parallel to the roof oder while leaving shout 8 cm (2.3 in) at the front where the
Installation	
	 Position the membrane parallel to the roof edge while leaving about 8 cm (3.2 in) at the front where the gutter will be installed. Fold back on itself, by half of its width, or 50 cm (20 in) over the whole length already positioned. It is recommended to kneel on the unfolded portion of the membrane to keep it in place during this operation. Remove the protective film from the folded section while placing the membrane on the support. The sefadhesive portion then adheres to the support. Then take the other side of the membrane and repeat the previous two steps. Immediately apply pressure on the membrane using a heavy metal roller or a hard rubber roller to ensure adhesion between the support and the membrane and avoid forming bulges, folds or gaps. Note: The transverse and longitudinal overlap should be 75 mm (3 in). Refer to ROOF SYSTEM INSTALLATION for waterproofing membrane installation to roof details and upstands.











