


RESISTO

H₂O PRIMER

PRIMER



Emulsion polymer based (water based) primer that is particularly recommended, when using a solvent-based primer is not recommended.

- Improves adhesion of self-adhesive membranes
- Easy and fast application
- Does not damage polystyrene

PRODUCT PURPOSE

| | | |
|---------------|--------------------------|-----------------------|
| Application | Waterproofing complement | |
| Building Part | Roofing | Showers and bathrooms |
| | Walls | |
| Substrates | Wood | Concrete |
| | Polystyrene | Gypsum |

PRODUCT CHARACTERISTICS

| | | |
|---------------------|--------------------------------------|---------|
| Installation Method | Paint brush | Sprayer |
| | Roller | |
| Maximum exposure | Once, dry, cover as soon as possible | |

PACKAGING

| Code | Containers | Indicative Covering Depending on the surface porosity* | Quantity per Pallet |
|-------|----------------------|---|---------------------|
| 30116 | 910 ml (0.25 US gal) | 55 - 90 ft ² (5 - 8 m ²) | 486 |
| 30112 | 3.78 l (1 US gal) | 208 - 340 ft ² (19 - 31 m ²) | 150 |
| 30111 | 18.9 l (5 US gal) | 608 - 1040 ft ² (56 - 96 m ²) | 36 |




PROPERTIES

| Properties | H ₂ O PRIMER |
|-----------------------------------|-------------------------|
| Color | Blue |
| Specific gravity at 20 °C (68 °F) | 1.00 kg/L |
| Solids by weight | 55% |
| Viscosity | 500 cP |

(All values are nominal)

H₂O PRIMER

INSTALLATION

| | | | |
|---------------------------------|--|-------------|--|
| Storage | Two years in its original closed packaging, in a cool, well-ventilated area. Store in a cool, dry place between 5 °C to 40 °C (41 °F to 104°F). | | |
| Minimum Application Temperature | 0 °C (32 °F). The product must be at a minimum temperature of 10 °C (50 °F) before application. | | |
| Tools Required |  | Paint brush |  |
| |  | Roller | |
| Surface preparation | The substrate must be clean and free of dust, grease or other contaminants. | | |
| Installation | <ol style="list-style-type: none"> 1. Mix the product before and during application. 2. Apply the product according to the chosen method. 3. Allow the primer to dry before installing the waterproofing membrane. 4. The primer is dry when sticky to the touch, but not messy. | | |
| Drying time | Between 30 minutes and 3 hours, depending on ambient temperature and the amount applied. | | |
| Cleaning | Clean wet tools with water. When the primer is dry, clean with solvents (mineral spirits, paint thinner, xylene, etc.). | | |
| Tricks / Tips | For greater efficiency, install the membrane or the sealing strip as soon as the primer is dry. | | |
| Recommendations/ Limitations | The membranes should be installed the same day as the application. Not suitable for plastic surfaces such as vinyl siding, or panels with a water-repellent surface treatment. Do not use to seal the self-adhesive membrane joints, as a coating between two membranes or asphaltic panels. | | |
| Warnings | Keep out of the reach of children. Properly close the container after each use. Keep out of the sun and away from ignition sources. Do not pour residues in drains. | | |

