
RESISTO

LASTOBOND PRO HT-S

EAVE PROTECTOR | UNDERLAYMENT



High performance self-adhesive underlayment for metal roofs, or as a perimeter membrane under one-ply roofing system and asphalt shingles. It is designed to withstand temperature variations from -45 °C to 126 °C (-49 °F to 260 °F).

- Excellent resistance to temperature variations
- Easy Installation
- UV resistant; 90-day exposure

PRODUCT PURPOSE

PRODUCT CHARACTERISTICS

Application	Waterproofing	
Building Part	Roofing	
Types of slope	Outside steep slope	Outside low slope
Type of covering	Metal roofing	Asphalt shingles
	Bitumen membrane	
Substrate	Plywood	Asphaltic panel
	OSB	

Technology	SBS modified bitumen
Surface	Trilaminate woven polyethylene
Underface	Two parts silicone release film (split-back)
Installation Method	Self-adhesive
Operating temperature	-45 ° C to 126 ° C (-49 ° F to 260 ° F)
Maximum exposure	90 days

PACKAGING

Code		Width		Length		Thickness		Gross Area	
Out	cm	in	m	ft	mm	mils	m²	ft ²	(per pallet)
10108 (With box)	91	36	20	65.6	1	40	18	195	25
10009 (Without box)	91	36	20	65.6	1	40	18	195	36

PROPERTIES

Properties	STANDARDS	LASTOBOND PRO HT-S
Thickness	-	1.0 mm (40 mils)
Roll Weight	-	20 kg (44 lbs)
Breaking Strength, MD / XD	ASTM D1970	11 / 12 kN/m (63 / 68 lbf/in)
Elongation at break, MD / XD	ASTM D1970	30 / 20%
Tear Resistance, MD / XD	ASTM D1970	375 / 400 N (84 / 90 lbf)
Static Puncture	ASTM D5602	400 N (90 lbf)
Adhesion to plywood, 4,5 $^{\circ}$ C (40 $^{\circ}$ F)	ASTM D1970	1.6 kgf/30.5 c, (3.5 lbf/in)
Adhesion to plywood, 24 °C (75 °F)	ASTM D1970	25 kgf/30.5 cm (55 lbf/in)
Low Temperature Flexibility	ASTM D1970	Pass at -30 °C (-22 °F)
Water vapour permeance	ASTM E96 (PROCÉDURE B)	< 2.1 ng/Pa.s.m ² (< 0.037 perm)
Nail Sealability	ASTM D1970	Pass

RESISTO

LASTOBOND PRO HT-S

INSTALLATION

Storage	protective cover after removing the del	e up. If the products are stored outdoors, cover them with an opaque ivery packaging. activated to at least 10 ° C (50 ° F) before installation.
Minimum Application Temperature	10 °C (50 °F)	
Complementary Products	EXTERIOR PRIMER	OR H ₂ O PRIMER
Tools Required	Knife	Smoothing roller
	Tape measure	

with RES Installation 1. If 2. F	use of EXTERIOR PRIMER or $\rm H_2O$ PRIMER is not required on most surfaces when the membrane is covered nin 24 hours of installation. However, primer is mandatory when membrane is used as underlayment in a ISTO single-ply roofing system. If conditions require, prepare the substrate with EXTERIOR PRIMER or $\rm H_2O$ PRIMER. Position the membrane parallel to the roof edge while leaving about 8 cm (3.2 in) at the front where the putter will be installed.
2. F	Position the membrane parallel to the roof edge while leaving about 8 cm (3.2 in) at the front where the putter will be installed.
r 4. F 2 5. T 6. I a Not	Fold back on itself, by half of its width, or 50 cm (20 in) over the whole length already positioned. It is ecommended to kneel on the unfolded portion of the membrane to keep it in place during this operation. Remove the protective film from the folded section while placing the membrane on the support. The self-adhesive portion then adheres to the support. Then take the other side of the membrane and repeat the previous two steps. In the membrane using a heavy metal roller or a hard rubber roller to ensure adhesion between the support and the membrane and avoid forming bulges, folds or gaps. Example: The transverse and longitudinal overlap should be 75 mm (3 in). Example: The ROOF SYSTEM INSTALLATION for waterproofing membrane installation to roof details and upstands.











