



(i): Always install Sopradrain 10G, 15G or 18G filter fabric towards soil retention system. Primer is recommended over drainage board for application below 10°C.

(ii): Primer + Colphene BSW Protect'R are required over Colphene BSW V for application under high water table level mark / high hydrostatic head.

(iii): COLPHENE BSW V and COLPHENE STICK LAP reinforcement installed over primed surface and all edges sealed is an acceptable alternative to COLPHENE BSW H and COLPHENE SP LAP reinforcement.

COPYRIGHT 2017 SOPREMA

Title:

BLINDSIDE WATERPROOFING - VERTICAL PENETRATION - BELOW 5 ° C

Scale:

N.T.S.

Date:

May 2017

Drawing number:

SOP417-04

