
SOPRA-FOAM GAPS AND CRACKS

INSULATING FOAM POLYURETHANE (PU)





FEATURES AND BENEFITS

- · Withstands building and material movement
- Insulates and seals gaps up to 2.5 cm (1 in)
- Adheres to most building materials

RECOMMENDED USES

- · Indoor and outdoor use
- Single-component polyurethane foam recommended for filling and insulating holes, cracks and joints
- To provide airtight insulation for wiring, plumbing and HVAC duct applications
- For applications requiring permanent adhesion to vinyl, wood, metal, polystyrene and polyiso



SURFACE PREPARATION

Before application, surfaces must be clean, homogeneous and free of all contamination (oils and greases, dust and loose or friable particles). Cement laitance must be removed. Dry and porous surfaces must be moistened with water.

APPLICATION

STRAW METHOD

Shake the SOPRA-FOAM GAPS AND CRACKS cartridge, remove the protective cap, and attach the straw to the cartridge. Do not overtighten. Hold cartridge down while applying foam. Shake the cartridge intermittently during prolonged use.

APPLICATOR GUN METHOD (PRO)

Shake the SOPRA-FOAM GAPS AND CRACKS cartridge before use. Remove the protective cap and screw the cartridge onto the applicator gun. Press the gun trigger to dispense the foam. Shake regularly during application. Always keep container upside down during application. Read gun manufacturer's instructions for proper use of application tool.

The cartridge can be left screwed onto the gun for up to 30 days when the screw on the back of the gun is tightened. The container must be under pressure, otherwise the foam will harden in the gun. NEVER leave an applicator gun without a foam cartridge attached unless it has been cleaned with SOPRA-FOAM CL-F cleaner.

Do not fill the entire space to allow the foam to expand. Expansion may vary according to ambient temperature and humidity level. In dry conditions, we recommend filling gaps in several thin layers (≤ 1 in). Ensure that each layer can harden and expand sufficiently. Spray water on the foam to accelerate curing if necessary.

The foam can be sanded, painted or stained after 24 hours.

LIMITATIONS

Avoid use in areas requiring fire-retardant or fireproof materials.

SOPRA-FOAM GAPS AND CRACKS is not suitable for silicone and PTFE substrates.

PROPERTIES

PROPERTIES		STANDARDS	SOPRA-FOAM GAPS AND CRACKS	
			STRAW	PRO
Surface burning characteristics (1),	Flame spread rating Smoke developed classification	UL 723	10 20	
Tack-free ⁽¹⁾ , 1 cm wide		ASTM C1620	7 ± 3 minutes	6 ± 2 minutes
Trim time ⁽¹⁾ , 1 cm wide		ASTM C1620	30-45 minutes	20-45 minutes
Curing time ⁽¹⁾	me ^(l) - 24 hours		ours	
Service temperature		-	-40 to 80 °C (-40 to 176 °F)	

⁽I): These numerical flame spread values are not a true reflection on how this or any material will perform in actual fire conditions.

CLEANING

Use SOPRA-FOAM CL-F cleaner to clean the applicator gun as soon as a container of SOPRA-FOAM GAPS AND CRACKS is removed and the gun is no longer in use, to prevent the foam from hardening inside the gun. Follow the instructions on the SOPRA-FOAM CL-F cleaner data sheet. Hardened foam can be removed manually; it is not harmful.

STORAGE AND HANDLING

SOPRA-FOAM GAPS AND CRACKS cartridges can be stored for 18 months from the date of manufacture if left in their original, unopened packaging. Store cartridges upright in dry conditions, out of direct sunlight and at temperatures between 5 and 25 °C (41 and 77 °F).

For more information and advice on the safe handling, storage and disposal of the chemical products, users shall refer to the most recent Safety Data Sheet (SDS) containing physical, ecological, toxicological and other safety related data.



^{(2):} Times were established at a temperature of 23 °C (73 °F) and 50% relative humidity. Reaction times will be slower at lower temperatures and drier air. (All values are nominal)